

Lahoux D-545

Night Vision Front Attachment



The multifunctional front attachment Lahoux D-545 is an improved version of our previous attachments. It is small, strong and lightweight, equipped with modern features like a silent push button and automatic shut-down after 90 minutes. Attaching the Lahoux D-545 to primary day optics, for instance scopes or camera's, is possible with an adapter, making the Lahoux D-545 an excellent choice for many outdoor activities. The Lahoux D-545 is available with all Photonis™ Image intensifier tubes in green and Onyx™. We recommend Supergen™, XD-4™, XR5™ or High FOM.

Advantages of the Lahoux D-545

- » User-friendly, simple operation
- » The Lahoux D-545 doesn't influence the optical precision
- » Compact and lightweight with modern design
- » 25 % more light transmission due to high contrast lenses
- » Equipped with rugged Photonis™ Image intensifier tube
- » Shock resistant mounted lenses and image intensifier tube
- » Sideways mounted battery compartment for improved reliability
- » F-Version with bigger ocular for higher magnification



Lahoux D-545

Night Vision Front Attachment

Technical Specifications	
Optics	
Magnification	1.0 x
Field of view	8,8 °
Lens	78 mm
Relative aperture	F/1.5, T/1.6 High Contrast
Ocular diameter	25 mm (34 mm with F-version)
Typical accuracy	< 1 MOA
Parallax	100 m
Focus range	10 m until ∞
Image Intensifier Tube	
Tube	Photonis™ Tube
Operational Parameters	
Temperature range	-40 °C to 50 °C
Waterproof	IP67
Battery	1x CR123A
Lifetime battery	60 - 90 hours
Size (L x B x H)	194 x 63 x 67 mm
Weight without battery	0,55 Kg

Optional Accessories

- » Infrared diode 75 mW including Weaver Adapter
- » Infrared diode 150 mW including Weaver Adapter
- » Laser illuminator including mounting bracket
- » Quick mounting ring for 2x monocular
- » Adapter, available in almost all sizes
- » 6x Monocular (only with F-version)
- » Manual gain control (EGAC)
- » Lahoux Helios illuminator
- » F-Version (bigger ocular)
- » P43 Phosphor option
- » SHD-50 Sunshade
- » 2x Monocular
- » 4x Monocular

Included Accessories

- » Twee accessory mounting rails
- » Quick Start Guide
- » 1 x CR123 battery
- » Carrying bag
- » Ocular cap
- » Lens tissue
- » Lens cap

F-Version with bigger ocular



Adapter



Official Lahoux Optics Dealer

